



# Do-It-Yourself Installation

## PRODUCTS

### EZ Arch Kits

- Starting @ \$202

### CBS Arch Kits

- Starting @ \$385

### Solid Wood Arch Kits

- Starting @ \$572

### Continuous Molding Kits

- Starting @ \$472

### Ceiling Kits

- Starting @ \$750

### Remodeling?

Easy Installation

### New Construction?

Framing & Installation

### Get a Price

### Videos

### Glossary / All About Arches

### Framing Specs

### Gallery

### About Us

### Contact Us

### Site Map

[View Our Installation Videos Here!](#)

**"It's the template that makes a CurveMakers Arch so easy to install."**

-Janie Johnson, Homeowner

**Fast and Easy installation is a feature that makes a CurveMakers Arch so attainable. You can do it, see for yourself.**



1. Remove existing casing in opening.

2. Nail blocks in corners of opening on which to attach new sheetrock.



3. Cut a piece of sheetrock to fit top of opening and install.



4. Slip columns on wall; rest template on top; draw arch shape.



5. Remove existing sheetrock; patch.



6. Apply sheetrock mud to seams and sand smooth.



7. Slip arch header onto wall.



8. Slip arch columns under header.



9. Level horizontally; nail all parts into place.

**That's all there is to it!**

[View Complete Instructions - PDF](#)



[Print this Page: Printer-Friendly PDF](#)

### View Complete Framing Specifications:

- E-Z Arch Kits: [New EZ Arch](#), [445 EZ Arch](#), [470 EZ Arch](#), [RB3 EZ Arch](#)
- Custom Builder Special Arch Kits: [Model CBS 3](#), [Model CBS 4](#), [Model CBS 5](#)
- Solid Wood Arch Kits: [Model L](#), [Model B](#), [Model C](#), [Model A](#), [Model J](#), [Model R](#)
- Continuous Molding Arch Kits: [Model CM](#)

